



## GruvenParts.com Corrado Billet Hood Clip Installation Instructions

Remove Handle Bracket from vehicle. Leave existing hood cable in place. Discard OEM stamped steel cable clip. Install Billet Hood Clip as shown. Reinstall Handle Bracket and slide cable in from side. Reconnect Handle to cable end.